

Satellite Sprayer/Foamer

Spraying and Foaming Options Where You Need Them

The Satellite Sprayer/Foamer delivers the economy and flexibility of the Satellite series in a versatile and convenient foaming, spraying and rinsing system.

The Satellite Sprayer/Foamer allows the user to choose either the foaming or spraying nozzles to apply a rich foam or spraying solution (e.g., sanitizer), then disengage the chemical supply for rinsing using the integrated switch-to-rinse toggle. Easily select either a wide-angle spraying pattern or powerful jet stream simply by rotating the rinse-pattern selector.

- Mobile: Take it anywhere! You don't need to attach it to a wall or buy a cart; it goes anywhere you can find water and carry your chemical container.
- Includes patented AccuPro pressure regulation technology: No more fluctuating dilution rates as water pressure varies; your dilution rate is always consistent across a wide range of pressures. And that means your product performs as it's supposed to!
- Unbeatable versatility; choose from either the foaming or spraying nozzles.





The Satellite Series Sprayer/Foamer Features

- Easily select a wide-angle spraying pattern or powerful jet stream simply by rotating the rinse-pattern selector.
- Handy On/Off trigger: Easy to operate with one hand
- Activate the Satellite with the On/Off trigger, then lock it in the "On" position all with one hand!
- Overmolded handle: For safe, sure gripping.
- Adjustable velcro strap for container stability: Allows you to secure either an F-style or round bottle to the Satellite for better balance.
- Multiple dilution rates: Pick from 14 different dilution rates using the metering tips included with the Satellite. Additional tips available.
- Easy connections to water source: Use one of the optional connectors for quick and easy access to almost any water source.

Water Source Connectors







Model 5820

Model 5830

Model 5840

Satellite Mobile Dispensing System Models

Approximate Dilution Range

Model	Description	Flow Rate (GPM)	Max.	Min.
5823	Initial container position set-up for F-style containers	2.5	280:1	7:1
5824	Initial container position set-up for round containers	2.5	280:1	7:1
5825	Initial container position set-up for F-style containers w/ RiteConnect	2.5	280:1	7:1
5826	Initial container position set-up for round containers w/ RiteConnect	2.5	280:1	7:1
5827	Initial container position set-up for SMP	2.5	280:1	7:1

