I. SCOPE OF THIS DOCUMENT:

This document describes in brief, how to install the Antares Programming Editor Software from Hydro Systems Company.

II. ABOUT 'ANTARES PROGRAMMING EDITOR':

Antares Programming Editor is a configuration editor software for creating/ editing Configuration files for DM6000 Dishwasher equipment system from Hydro Systems Company. This document serves as a guide to installing Antares Programming Editor, version 1.0.0.

III. REQUIREMENTS:

To Install 'Antares Programming Editor' Software, the following minimum hardware configuration requirements are to be met:

a. Requirements for Windows:

A PC running Windows XP or higher version of OS.

Minimum of 1 GB of RAM, 1.6 GHz of processor.

At least 30 MB of free hard-disk space.

Java Runtime Environment 8.0 or Higher is mandatory for running the application. (Please visit www.java.com for more information on JRE 8.0 requirements).

b. Requirements for MAC:

A MAC PC running MACOS X, version 10.7.1 or higher

Minimum of 1 GB of RAM, 1.6 GHz of processor.

At least 30 MB of free hard-disk space.

Java Runtime Environment 8.0 or Higher is mandatory for running the application. (Please visit www.java.com for more information on JRE 8.0 requirements).

IV. PRE-REQUISITES:

As part of the installation process care is taken to perform a check for pre-requisites. For successful running of the application, the following pre-requisite has to be met before the Software can be run.

a. The User must be an Administrator user on the PC where the Software has to be installed, Contact your Administrator for more information about Administrator rights for your account in case if you are not sure!

b. While during the installation of the software on Windows, the installer checks for pre-requisite, but as a best practise it is good to have the pre-requisite installed before installing the Antares Programming Editor.

c. To Run the Antares Programming Editor, Java Runtime Environment version 8.0 has to be installed.

V.   TO INSTALL JRE 8.0 OR HIGHER: (APPLIES TO BOTH WINDOWS AND MACOS)

i.   Visit the website www.java.com from the default browser.
ii.   Follow the instructions and perform "Free Java Download"
iii.   The Installation is pretty automatic, and should complete with in few minutes. (Depending on the internet speed).
iv.   Once JRE is installed, perform a Reboot as required.

VI.   TO INSTALL ANTARES PROGRAMMING EDITOR VERSION 1.0.0:

A. FOR INSTALLATION ON WINDOWS OS:

i.   To Install the Antares programming Editor on Windows, open the Installation binary – setup.exe, received from Hydro Systems Company.
ii.   Make sure that all the pre-requisites are met as in section IV above.
iii.   Double click on the setup.exe binary:

Once double click, you may be prompted for elevation of privileges by the 'User Access Control', on a Windows 7 OS or higher, click 'yes' if asked.

The next step, the installer will verify for Prerequisites. The Wizard starts with the Prerequisites window.


Figure 1. Prerequisites Check.

Click Next:

Figure 2. Java Runtime Environment Installation option.

The next window prompts for installing the latest Java Runtime Environment. For Refer Section IV for more details about JRE requirements. For running the Antares Programming Editor, JRE version 8.0 is minimum. If you have already installed the JRE, Click Finish at this stage.

Click Next:

The default browser will pop-up to the website www.java.com

Figure 3. JRE portal.

Download the latest JRE by clicking the Free Java Download Button, and following the Online installation instructions from Java.

Return back to the installer:

Figure 4. Wizard to End the Prerequisite.

Click 'finish' at this step.

Prerequisite steps are over.

The Main Installation Wizard will start the installation:

Figure 5.Antares Programming Editor – Wizard Main screen.

Click "Next" in this window:

Figure 6. Antares Programming Editor – Choose A Path.

Select a path (or use the default path) if you want the installation to happen in a different directory.

Click Next, Click Install:

Figure 6. Antares Programming Editor – Install Now…

Installation should take minutes to complete:

Figure 6. Antares Programming Editor – Install Now…

Click Finish:

Figure 7. Antares Programming Editor – Install Ends.

Shortcuts to the Application:

Figure 7. Antares Programming Editor – Shortcuts,

Find a Shortcut to Antares Programming Editor on Desktop and in the start menu. Click the Shortcut to launch the application.

Uninstalling the Antares Programming Editor:

For Uninstalling the Antares Programming Editor from Windows, Use the Add Remove Programs window from Control Panel.

In the Add Remove programs a Entry will be available with Name Antares Programming Editor:

Uninstall the Antares Programming Editor from this shortcut.

B. FOR INSTALLATION ON MACOSX:

i.   To Install the Antares programming Editor on MACOSX, copy the Installation binary – setup.zip, received from Hydro Systems Company, onto the desktop.

ii. Make sure that all the pre-requisites are met as in section IV above.

iii. To run the "Antares Programming Editor" JRE 8.0 is a minimum requirement.

iv. Copy the setup.zip file to a convenient location, preferably the Applications folder, from desktop.

v.   Now double click the setup.zip to extract the application.

vi. The Application can be run from the extracted Application package file.

vii. Double click the Antares programming Editor Package file, to run the application.

viii. At any time if you wish to remove the application, just delete the folder containing the package file.